

Mini Coyote v2 – User Manual

General Features

Information Display

The display of the Mini Coyote v2 initially shows alerts in a pop-up window that fills the whole screen and then reduces in size to display in the bottom half of the screen. In minimised mode, you will always have the current speed limit, your GPS speed and the battery level displayed in the top half of the screen.

Speed indications on screen:



Mini Coyote v2 permanently displays your current speed. This is the GPS calculated speed

Mini Coyote v2 permanently displays the current speed limit in a speed limit panel, in the top left-hand corner of the screen. It also displays the name of the road you are driving on (when available)



Speed limit panel when you are driving under the speed limit (\pm limit threshold, see Menu → Road Safety → Speed Limit → Speed Limit Alerts).



Speed limit panel when you are driving over the speed limit (\pm limit threshold, see Menu → Road Safety → Speed Limit → Speed Limit Alerts)

DISTRIBUTED IN THE UK BY

Cobra UK Limited

Crossgate House

Cross Street

Sale

Cheshire

M33 7FT

Tel: 0845 504 8969

info@coyotesystems.co.uk

www.coyotesystems.co.uk

Coyote Scouts

Coyote's key aim is to contribute to road safety by encouraging Scouts (users) to respect the rules of the road. Each Scout can communicate the presence of traffic incidents and / or live mobile cameras to the Coyote Community by the simple press of a button. So each and every scout is constantly contributing to the quality and reliability of the data transmitted to the Community. To become a good Scout, all you need to do is to communicate incidents and answer questions asked by your Mini Coyote v2 during your journey. The Scout confidence rating is central to the whole philosophy of the Coyote Community. Therefore, your Coyote Scout rating evolves over time and is based on the frequency and reliability of communication. The more a Scout actively communicates, the more their confidence rating increases. Little or no active participation will lower your Scout confidence rating.

To view your confidence rating, go to the Subscriber Info page on your Coyote device (Menu → Coyote → Subscriber Info).


You will see 2 types of Scouts display on your Mini Coyote v2:

Town Mode:



In minimised mode, your Mini Coyote v2 will display the number of Scouts (12 are shown in the example picture) within the given radius (3 miles).





In maximised mode, your Mini Coyote v2 will display the same information as above but also the type () and name (B368) of the road you are driving on.


Road Mode:



In minimised mode, your Mini Coyote v2 will display the number of Scouts (12 are shown in the example picture) who have passed the same point in the last half hour. It also displays the distance between you and the nearest Scout (1 mile in the example).



In maximised mode, your Mini Coyote v2 will display the same information as above but also the type (Motorway  or A-road ) and the name (M25) of the road.

The Scout confidence () displayed on the screen indicates the average confidence rating of the Scouts who have passed the same point in the last half hour.

DISTRIBUTED IN THE UK BY

Cobra UK Limited

Crossgate House

Cross Street

Sale

Cheshire

M33 7FT

Tel: 0845 504 8969

info@coyotesystems.co.uk

www.coyotesystems.co.uk

Live event reporting:



To report a live Speed Camera in your direction, press button “A”

To report a live Speed Camera in the opposite direction, press button “C”

To report a Traffic Incident (in your direction) press button ‘B’.



To confirm the presence of a live Mobile Camera, press the ‘yes’ button (C)

To exclude the presence of a live Mobile Camera, press the ‘no’ button (A)

DISTRIBUTED IN THE UK BY

Cobra UK Limited

Crossgate House

Cross Street

Sale

Cheshire

M33 7FT

Tel: 0845 504 8969

info@coyotesystems.co.uk


www.coyotesystems.co.uk

Settings

Standard Menu:




Menu → Road Safety



Settings for all safety features

Menu → Road Safety → Speed Limit




Speed limit panel settings

Menu → Road Safety → Speed limit → Display



Only displays verified speed limit or all speed limits (including those that are unverified)

Menu → Road Safety → Speed limit → Overspeed



When the real-time speed is above the limit (\pm limit percentage), this screen allows you to decide how your Coyote will warn you.

DISTRIBUTED IN THE UK BY

Cobra UK Limited

Crossgate House

Cross Street

Sale

Cheshire


M33 7FT

Tel: 0845 504 8969

info@coyotesystems.co.uk


www.coyotesystems.co.uk

Menu → Road Safety → Speed Limit → Speed limit alerts




Speed limit alert settings

Menu → Road Safety → Speed limit → Transition




This screen allows you to specify how you want Mini Coyote v2 to inform you about speed limit changes on your route

Menu → Road Safety → Traffic alerts




This screen allows you to specify how you want Mini Coyote v2 to warn you about traffic alerts

Menu → Road Safety → Scouts alerts



This screen allows you to specify how you want the Mini Coyote v2 to warn you about alerts notified by other users.

Menu → Road Safety → Blackspots



This screen allows you to specify how you want Mini Coyote v2 to warn you about blackspot zones

DISTRIBUTED IN THE UK BY

Cobra UK Limited

Crossgate House

Cross Street

Sale

Cheshire


M33 7FT

Tel: 0845 504 8969

info@coyotesystems.co.uk

www.coyotesystems.co.uk

Menu → Camera alerts




All camera alert settings

Menu → Camera alerts → Fixed cameras



Fixed speed camera alert settings

Menu → Camera alerts → Fixed cameras → Alert type



This screen allows you to specify how you want Mini Coyote v2 to warn you about Fixed Speed Cameras

Menu → Camera alerts → Fixed cameras → Alert distance




Alert distance settings

Menu → Camera alerts → Fixed cameras → Alert distance → Distance city



This screen allows you to set the distance settings for receiving alerts in cities

Menu → Camera alerts → Fixed cameras → Alert distance → Distance road



This screen allows you to set the distance settings for receiving alerts on A, B or C roads

UK BY

Cobra UK Limited
 Crossgate House
 Cross Street
 Sale
 Cheshire
 M33 7FT
 Tel: 0845 504 8969
 info@coyotesystems.co.uk

Menu → Camera alerts → Fixed cameras → Alert distance → Dist. Motorway



This screen allows you to set the distance settings on motorways

Menu → Camera alerts → Fixed cameras → Alert threshold



Set the speed limit for Fixed camera alerts.

Menu → Camera alerts → Live cameras



Live cameras alerts settings

Menu → Camera alerts → Live cameras → Alert type

This works in the same way as for Fixed speed cameras

Menu → Camera alerts → Live cameras → Alert distance

This works in the same way as for Fixed speed cameras

Menu → Camera alerts → Live cameras → Alert distance → Distance City

This works in the same way as for Fixed speed cameras

Menu → Camera alerts → Live cameras → Alert distance → Dist. Motorway

This works in the same way as for Fixed speed cameras

Menu → Camera alerts → Live cameras → Alert threshold

This works in the same way as for Fixed speed cameras

DISTRIBUTED IN THE UK BY

Cobra UK Limited

Crossgate House

Cross Street

Sale

Cheshire

M33 7FT

Tel: 0845 504 8969

info@coyotesystems.co.uk

www.coyotesystems.co.uk

Menu → Camera alerts → Risk areas



Risk areas alerts settings

Menu → Camera alerts → Risk areas → Alert type

This works in the same way as for Fixed speed cameras

Menu → Camera alerts → Risk areas → Alert distance

This works in the same way as for Fixed speed cameras


Menu → Camera alerts → Risk areas → Alert distance → Distance city

This works in the same way as for Fixed speed cameras

Menu → Camera alerts → Risk areas → Alert distance → Dist. Motorway

This works in the same way as for Fixed speed cameras

Menu → Camera alerts → Risk areas → Alert frequency



Set the risk zone alert according to the time of the day (morning / afternoon / night)

Menu → Camera alerts → Risk areas → Alert threshold

This works in the same way as for Fixed speed cameras

DISTRIBUTED IN THE UK BY

Cobra UK Limited

Crossgate House

Cross Street

Sale

Cheshire


M33 7FT

Tel: 0845 504 8969

info@coyotesystems.co.uk


www.coyotesystems.co.uk

Menu → Settings



Various settings

Menu → Settings → Volume



Volume settings

Menu → Settings → Brightness



Brightness settings

Menu → Settings → Brightness → Value




Brightness intensity settings

Menu → Settings → Brightness → Eco battery



Conserve battery life by reducing screen brightness when idle

Menu → Settings → Brightness → Day / night mode



Adapt the screen brightness according to daylight (also displays the sunset and sunrise time for the current day)

DISTRIBUTED IN THE UK BY

Cobra UK Limited
 Crossgate House
 Cross Street
 Sale
 Cheshire
 M33 7FT
 Tel: 0845 504 8969
 info@coyotesystems.co.uk

www.coyotesystems.co.uk

Menu → Settings → Key beep



Enable / disable the sound produced when pressing the keys

Menu → Settings → Audio on helmet (Motorcycles only)



Activate the Mini USB audio output (for customers who have purchased the Motorcycles Accessory Kit)

Menu → Settings → Auto shutdown



Automatically shutdown Mini Coyote v2 when parked
“On USB power”:if you activate this option, Mini Coyote v2 will automatically shutdown when there is no power from the USB cable (car adapter). This is so the Coyote automatically shutdown when you switch off your ignition. Please be aware that the cigar lighter in some makes of vehicle does not switch off automatically when the ignition is switched off and we do not recommend using this setting in such instances.

DISTRIBUTED IN THE UK BY

Cobra UK Limited

Crossgate House

Cross Street

Sale

Cheshire


M33 7FT

Tel: 0845 504 8969

info@coyotesystems.co.uk

www.coyotesystems.co.uk

Menu → Coyote Scouts



Scout alerts settings

Menu → Coyote Scouts → City / Countryside



Set up Town Mode for urban and non urban use. If 'no' is selected, Mini Coyote v2 will display Scouts information only on major roads and Motorways

Menu → Coyote Scouts → Major roads



Show the scouts in your direction or in both directions. Mini Coyote v2 will show you the number of other users that have passed the same point in the last half hour

Menu → Coyote Scouts → Update beep



Generates a beep each time Scouts information is received

Menu → Coyote Scouts → Scout confidence



Communicate your confidence in the Coyote Community. This menu will suppress the audio warning for a Risk Zone depending on the Rating of the Scout who provided the information

DISTRIBUTED IN THE UK BY

Cobra UK Limited

Crossgate House

Cross Street

Sale

Cheshire


M33 7FT

Tel: 0845 504 8969

info@coyotesystems.co.uk

www.coyotesystems.co.uk

Menu → Coyote




Menu → Coyote → Subscriber info



This page tells you your subscription end date and your own scout Confidence rating. This is determined automatically based on your participation in the Community.

Menu → Coyote → Coyote info




This page gives you information about the product itself (identification number, software version, battery level) and its connection to the world (GSM and GPS) The GSM line shows the reception level, a letter indicating the server Connection status and the operator name. This letter should be 'F'. If the GPS number is green, your system is functioning normally.

Menu → Coyote → Autotest

This is an auto diagnostic tool.

Follow the instructions on the screen. The Autotest is successful if all field values are green.



Screen: By following the instructions on screen, you can test the screen, sound and key functionality

GPS: If you are in an area with GPS coverage, the number of GPS satellites should increase and turn green. This means that Mini Coyote v2 was able to determine its location

SIM: If the SIM card is functioning normally the name of the provider is displayed in green

GSM: When Mini Coyote v2 connects to the GSM network and establishes a GPRS connection, 'GPRS' and the signal strength are displayed in green

Server: When Mini Coyote v2 successfully connects to the Coyote Servers, 'OK' is displayed in green

Subs: If the subscription is still live, Mini Coyote v2 displays the end date in green

Battery: When the battery is being charged, the level of charge is shown in green

DISTRIBUTED IN THE UK BY

Cobra UK Limited

Crossgate House

Cross Street

Sale

Cheshire

M33 7FT

Tel: 0845 504 8969

info@coyotesystems.co.uk

www.coyotesystems.co.uk


Menu → Coyote → Demo

This launches the Mini Coyote v2 Demo showing examples of different types of alert that you may encounter on the road

Menu → Coyote → Reset




Restores the factory settings and the GPS chip data



Menu → Languages



Driving menu



The driving menu is accessed by pressing the middle button for more than 2 seconds when driving (when real-time speed is over 3mph)

Driving menu → Sound



You can quickly mute the sound or restore it

DISTRIBUTED IN THE UK BY

Cobra UK Limited

Crossgate House

Cross Street

Sale

Cheshire

M33 7FT

Tel: 0845 504 8969

info@coyotesystems.co.uk


www.coyotesystems.co.uk

Driving Menu → Send wrong speed



Mini Coyote v2 allows you to indicate a wrong speed limit on the road section that you are travelling on. Please adjust the speed limit by pressing the **-** or **+** button and when you have reached the correct value, press the **OK** button. The correction will be sent to our servers and be corrected on the database.

Driving Menu → Send Fixed Camera




Mini Coyote v2 allows you to report a fixed camera on the road section you that you are currently on. This notification will be sent to our servers for verification.

Driving Menu → Menu

From the Driving Menu, you can access the Standard Menu. We strongly recommend that you do not alter settings etc whilst driving.

Driving Menu → Turn off



You can switch off Mini Coyote v2 from the Driving Menu at any time (if you are not already in a menu) by pressing the left button and holding it down for more than 2 seconds.

DISTRIBUTED IN THE UK BY

Cobra UK Limited
Crossgate House
Cross Street
Sale
Cheshire
M33 7FT
Tel: 0845 504 8969
info@coyotesystems.co.uk

www.coyotesystems.co.uk